

MODEL 2409/2609



MODELS ON VOSTOK 2409 MOVEMENT & POLJOT 2609 MOVEMENTS MANUAL WINDING

Crown of the watch has 2 positions:

- a – mainspring winding;
- b – time setting.

To unscrew the crown:

1. Turn it counterclockwise until tight.
2. Then you can wind the mainspring or pull crown out for time setting (Pos. “b”). To screw in the crown:

1. Return the crown in Pos. “a”.
2. Turn crown clockwise while pressing it lightly until tight.

WATCH WINDING

Turning the crown clockwise in the Pos. “a” winds up the mainspring of the watch.

- Do not apply excessive strains to the crown, it can result in a breakage of the winding device or the mainspring.