

## MODEL 515.24...

**INDICATION:** During the calendar jump phase between **10.30 pm and 00.00 am** the date can be changed. In this case the date of the following day needs to be set as there will be no jump at midnight.

### **Stem position 1**

– Home position, watch runs

### **Stem position 2**

– Quick change of the date ( clockwise), watch runs

– Quick change of GMT( 24h indication – counterclockwise), watch runs

### **Stem position 3**

– Hand-setting, watch stops

– when stem pulled out, save up to 70% energy

